Crosman CORPORATION

CROSMAN PNEUMATIC RIFLE

MODEL 120 **Single Shot** **.22 Caliber**



Operating Instructions

1. Cock rifle by turning bolt knob to unlock and drawing bolt back until trigger sets with audible click. Leave bolt open.
2. PUMP RIFLE. Most efficient performance will be obtained using 4 to 8 full quick strokes. In no case use more than 10 strokes and then only with a completely empty pressure chamber.
3. Lay pell in loading channel, blunt nose forward, and push into breech with bolt until bolt knob can be locked.
4. When conditions are safe, - aim and shoot.

ALWAYS FOLLOW THESE SIMPLE SAFETY RULES

(Gun accidents do not happen, they are caused.)

1. Treat every gun as if it were a loaded gun until you have personally proven otherwise.
2. Keep muzzle of gun pointed in safe direction.
3. Be sure of your backstop.
4. Conduct yourself as a true sportsman at all times.



Crosman CORPORATION

Care of Model 120 Crosman Rifle

1. Use good grade light machine oil sparingly on all moving parts. Do not use penetrating oils as they are harmful to valve seals.
2. DO NOT put oil in air intake hole on underside of pump tube.
3. Keep gun clean to prevent foreign matter entering valve action.
4. If pell lodges in barrel use a ramrod, do not attempt to shoot it out with another pell. It will only jam harder. Take care not to damage precision rifling.
5. Keep several strokes of pressure in rifle when not in use to maintain valve efficiency.
6. Use of Crosman Super Pells is recommended for greater accuracy, and longer barrel life.

HAVE MORE FUN WITH YOUR CROSMAN

See literature packed with gun for the complete Crosman line of accessories and targets engineered for your guns.

You can qualify for NRA Junior marksmanship with your Crosman. Write for free information.

IMPORTANT

This Crosman gun is guaranteed for ninety (90) days from date of purchase against defective material and workmanship.

Detach and mail the attached Application AT ONCE, in order to receive your Guarantee Certificate.

Warranty service WILL NOT be extended unless the gun is accompanied by a Guarantee Certificate.